

Features

OSP_{rey800} measures OSP coating thickness and quality *in-situ* on PCB/PWB. Measurements can be performed at various stages in its' lifecycle allowing the monitoring of adverse effects due to production steps and ageing on the OSP coatings. Predictions of solderability of the protected surfaces, for example, are possible at any stage during the PCB/PWB lifecycle.

• Metrology Principles

- Non destructive *in-situ* measurement of OSP coating thickness on PCB/PWB using reflectometry without any sample preparation
- A target area 330 µm x 265 µm is investigated in each measurement by mapping independent side-by-side lying 1 µm x 1 µm locations
- Measurements of OSP coatings on rough surfaces are possible
- Coatings of thicknesses 0.035 - 3 µm can readily be measured and analyzed
- Two-dimensional rendering of the OSP thickness morphology yields coating quality.
- Specific regions of interest can be targeted on a board allowing pointed quality control metrology, consequential failure analysis and troubleshooting of the OSP layer
- Small observation spot size provides the capability to investigate the OSP coating of individual features such as contact pads, etc.

- OSP_{rey800} metrology does not have any adverse effects on the PCB/PWB or on the OSP coating
- Measurements at various stages of the PCB/PWB lifecycle allow monitoring of undesirable effects due to production steps and ageing on OSP coatings

• Excitation

- Multi-wavelength optical excitation 420 - 665 nm

• Optics

- Imaging system with 20x optical magnification

• Analysis

- FILMeasure software for instrument control and data analysis
- Processing of wavelength dependent reflectance spectra from OSP coated PCB/PWB
- Programmable recipe editor for model and initial parameter definition

• Sample Stage

- Fixed in-plane XY sample stage
- Motorized z-axis optical column with autofocus

• Dimensions

- Measurement Stage: 25 W x 30 D x 46.5 H (cm)
- Controller Unit: 27.5 W x 20.7 D x 14.5 H (cm)

• Weight

- Measurement Stage: 6.6 kg (14.5 lbs)
- Controller Unit: 5.7 kg (12.5 lbs)

Oxford Instruments Industrial Analysis

UK

Halifax Road, High Wycombe
Bucks, HP12 3SE England
Tel: +44 (0) 1494 442255
Fax: +44 (0) 1494 461033
Email: analytical@oxinst.co.uk

China

Beijing
Tel: (8610) 6518 8160/1/2
Fax: (8610) 6518 8155
Email: info@oichina.cn

Finland

Espoo
Tel: +358 9 329 411
Fax: +358 9 3294 1300
Email: info@oxinst.fi

France

Saclay, Cedex
Tel: +33 (0) 1 69 85 25 24
Fax: +33 (0) 1 69 41 86 80
Email: analytical-info@oxford-instruments.fr

Germany

Wiesbaden
Tel: +49 (0) 6122 937 177
Fax: +49 (0) 6122 937 178
Email: analytical@oxford.de

Japan

Tokyo
Tel: +81 (0) 3 5245 3591
Fax: +81 (0) 3 5245 4466/4477
Email: oikkma@oxinst.co.jp

Latin America

Clearwater FL
Tel: +1 727 538 7702
Fax +1 727 538 4205
Email: oxford@gate.net

Singapore

Tel: +65 6337 6848
Fax: +65 6337 6286
Email: xrf.sales@oxford-instruments.com.sg


USA - Oxford Instruments Measurement Systems

Elk Grove Village IL
Tel: +1 847 439 4404
Fax: +1 847 439 4425
Email: sales@msys.oxinst.com

www.oxford-instruments.com

OSP_{rey800}

The revolution in OSP thickness measurement




click onto www.oxford-instruments.com for more information

Oxford Instruments, at High Wycombe, UK, operates Quality Management Systems approved to the requirements of BS EN ISO 9001. This publication is the copyright of Oxford Instruments Analytical Limited and provides outline information only which (unless agreed by the company in writing) may not be used, applied or reproduced for any purpose or form part of any order or contract or be regarded as a representation relating to the products or services concerned. Oxford Instruments' policy is one of continued improvement. The company reserves the right to alter, without notice, the specification, design or conditions of supply of any product or service. Oxford Instruments acknowledges all trade marks and registrations. *Patent number: EP 0325383; US 5170229

© Oxford Instruments Analytical Ltd, 2007. All rights reserved.

Part no: OIIA/017/B/0207



The Business of Science™



Determine OSP coating thickness and integrity on PCB/PWB

At last... non-destructive measurement on real-time production boards



OSPrey800 provides spectroscopic non-destructive optical metrology of OSP coatings using reflectometry. Thickness Measurements are performed *in-situ* and require no sample preparation. **OSP**rey800 measurements do not have any adverse effects on the PCB/PWB.



- ❑ **Accurate, non-destructive OSP thickness measurement**
- ❑ **Measure the real-production sample**
 - No more test coupons
 - No sample preparation
- ❑ **Maps OSP coverage of individual pads**
- ❑ **Intuitive controls designed for use by production personnel**

Introducing **OSP**rey800

OSPrey800 verifies the reliable application of OSP coatings returning quantitative thickness, integrity, reliability and film morphology observations of OSP on PCB/PWB.


- *In-situ* non-destructive measurements of OSP film thickness on PCB/PWB.
- Multiple thickness measurements of independent regions of $1\mu\text{m} \times 1\mu\text{m}$ surface area within a $330\mu\text{m} \times 265\mu\text{m}$ total surface area of the OSP film are simultaneously performed.
- Measurements of OSP coatings on rough surfaces are possible.
- Typical coating of thicknesses from $0.035 - 3\mu\text{m}$ can readily be measured and analyzed.
- Rendering of two-dimensional thickness maps of the OSP layer.
- Specific regions of interest can be targeted on a PCB/PWB allowing pointed quality control metrology, consequential failure analysis and troubleshooting of the OSP layer.

Intuitive User Interface



Measurement principle

The **OSP**rey800 measures thin-film characteristics by analyzing the spectral interference exhibited by reflecting light over wavelengths in the visible spectrum. Light reflected from the thin-film surface and the substrate surface will exhibit phase differences which lead to an interference pattern. This interference pattern exhibits intensity oscillations. The **OSP**rey800 analyzes the frequency and amplitude of these oscillations to determine the thickness and integrity of thin films.



Why choose OSP metrology?

UV-Visible Characterization

- No information on OSP thickness variation
- Destructive – requires test coupons
- Dependant on correct density factor for accuracy

Focused Ion Beam Method

- Labour intensive and expensive
- Destructive – requires sample coupons
- No information out of cross-sectioned plane

Sequential Electrochemical Reduction Analysis

- High potential of faulty measurement
- Destructive – requires test coupons
- No information on geometry of OSP layer

OSPrey800 Metrology

- Highly accurate measurement performed *in-situ*
- Characterizes real production boards – No test coupons
- Quantifies thickness, integrity and reliability of OSP coating

Unique Features

OSPrey800 offers non-destructive optical metrology of OSP coatings.

- A target area $330\mu\text{m} \times 265\mu\text{m}$ is investigated in each measurement by mapping independent side-by-side lying $1\mu\text{m} \times 1\mu\text{m}$ locations.
- Two-dimensional rendering of the OSP thickness morphology yields coating quality.
- Performed *in-situ* and requires no sample preparation after OSP application.
- **OSP**rey800 metrology does not have any adverse effects on the PCB/PWB.
- Measurements at various stages of the PCB/PWB lifecycle allow monitoring of undesirable effects due to production steps and ageing on the OSP coatings.